



## **LEDVANCE USER MANUAL**

### GRID-CONNECTED PV INVERTER

LT-40K F1

LT-45K F1

LT-50K F1

# CONTENTS

---

<b>INTRODUCTION</b>	<b>1</b>
Appearance Introduction	1
Labels Description	2
Parts List	3
Product Handling Requirements	4
<b>SAFETY WARNINGS AND INSTRUCTIONS</b>	<b>5</b>
Safety Signs	5
Safety Instructions	5
Notes for Using	6
<b>OPERATION INTERFACE</b>	<b>7</b>
Interface View	7
Status Indicator	7
Buttons	8
LCD Display	8
<b>PRODUCT INSTALLATION</b>	<b>9</b>
Select Installation Location	9
Installations Tools	11
Inverter Installation	11
<b>Electrical Connection</b>	<b>13</b>
PV Module Selection	13
DC Input Terminal Connection	13
AC Input Terminal Connection	15
The Connection of the Ground Line	17
Max. Over Current Protection Device	18
Inverter Monitoring Connection	18
Installation of Datalogger	19
Configuration of Datalogger	19
<b>STARTUP AND SHUTDOWN</b>	<b>20</b>
Start up The Inverter	20
Inverter Shutdown	20
<b>ZERO-EXPORT FUNCTION VIA ENERGY METER</b>	<b>21</b>
Multiple Strings and Parallel Connection Meters	26
Use of Zero-export Function	32
Notes While Using Zero Export Function	33
How To Browse The Load Power of Your Pv Grid-Tieplant on Monitoring Platform?	33
<b>GENERAL OPERATION</b>	<b>34</b>
The Initial Interface	37
Submenus In The Main Menu	38
System Param Setting	40
Protect Param Setting	41
Comm. Param Setting	43
<b>REPAIR AND MAINTENANCE</b>	<b>44</b>
<b>ERROR INFORMATION AND PROCESSING</b>	<b>45</b>
Error Code	45
<b>SPECIFICATION</b>	<b>50</b>
<b>EU DECLARATION OF CONFORMITY</b>	<b>53</b>

## About This Manual


The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

## How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter.

Documents must be stored carefully and be available at all times. **Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice.**

## Photovoltaic Grid-connected System




## INTRODUCTION


---

### Appearance Introduction

On-grid Inverter can convert solar panel DC power into AC power which can directly input to the grid. Its appearance is shown below. These models contain LT-40K F1, LT-45K F1, LT-50K F1. The following is collectively referred to as “inverter”.








Front view




Bottom view

## Labels description


LABEL	DESCRIPTION
	Caution, risk of electric shock symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.
	The DC input terminals of the inverter must not be grounded.
	CE mark of conformity
	Please read the instructions carefully before use.
	Symbol for the marking of electrical and electronics devices according to Directive 2002/96/EC. Indicates that the device, accessories and the packaging must not be disposed as unsorted municipal waste and must be collected separately at the end of the usage. Please follow Local Ordinances or Regulations for disposal or contact an authorized representative of the manufacturer for information concerning the decommissioning of equipment.

## Parts list


Please check the following table, to see whether all the parts are included in the package




Grid-tied PV String Inverter x1




Wall mounting bracket x1



Mounting stainless steel screws M4×12x3



DC+/DC- Plug connectors including metal terminalxN




Stainless steel anti-collision bolt M6×60x4




User manual x1




Wrench x 1




T-type wrenchx1




Datalogger (optional) x1




\*Sensor Clamp (optional)



Meter (optional) x 1




Solar Photovoltaic Connector Special Spanner x1



HJA4 Core Wire Female Connector - Screw Crimp x1

## Product handling requirements

Lift the inverter out of the packaging box and transport it to the designated installation location.



transport



### CAUTION

Improper handling may cause personal injury!

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by one or two people or by using a proper transport tool.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.

## SAFETY WARNINGS AND INSTRUCTIONS

---

Improper use may result in potential electric shock hazards or burns. This manual contains important instructions that should be followed during installation and maintenance. Please read these instructions carefully before use and keep them for future reference.

### Safety signs

Safety symbols used in this manual, which highlight potential safety risks and important safety information, are listed as follows:



#### **WARNING**

Warning symbol indicates important safety instructions, which if not correctly followed, could result in serious injury or death.



#### **SHOCK HAZARD**

Caution, risk of electric shock symbol indicates important safety instructions, which if not correctly followed, could result in electric shock.



#### **SAFETY HINT**

Note symbol indicates important safety instructions, which if not correctly followed, could result in some damage or the destruction of the inverter.



#### **HIGH TEMPERATURE HAZARD**

Caution, hot surface symbol indicates safety instructions, which if not correctly followed, could result in burns.

### Safety instructions



#### **WARNING**

Electrical installation of the inverter must conform to the safety operation rules of the country or local area.



#### **WARNING**

Inverter adopts non-isolated topology structure, hence must insure DC input and AC output are electrical isolated before operating the inverter.

**SHOCK HAZARD**

Prohibit disassembling inverter case, there existing shock hazard, which may cause serious injury or death, please ask qualified person to repair.

**SHOCK HAZARD**

When PV module is exposed to sunlight, the output will generate DC voltage. Prohibit touching to avoid shock hazard.

**SHOCK HAZARD**

While disconnect the input and output of the inverter for maintenance, please waits for at least 5 mins until the inverter discharge the remnant electricity.

**HIGH TEMPERATURE HAZARD**

Local temperature of inverter may exceed 80° while under operating. Please do not touch the inverter case.

**Notes for using**


The three phase string power inverter is designed and tested under related safety regulations. It can ensure the personal safety of the user. But as a electric device, it may cause shock or injury by incorrect operation. Please operate the unit under below requirements:

1. Inverter should be installed and maintained by qualified person under local standard regulations.
2. Must disconnect the AC side first, then disconnect DC side while doing installation and maintenance, after that, please wait at least 5 mins to avoid getting shocked.
3. Local temperature of the inverter may exceed 80 °C while under operating. Do not touch to avoid getting injured.
4. All electrical installation must be in accord with local electrical standards, and after obtaining the permission of the local power supply department, the professionals can connect the inverter to the grid.
5. Please take appropriate anti-static measure.
6. Please install where children can not touch.
7. The steps to start the inverter: 1) switch on the AC side circuit breaker, 2) Switch on the DC side circuit breaker of the PV panel. 3) Turn on the DC switch of the inverter. The steps to stop the inverter: 1) switch off the AC side circuit breaker, 2) switch off the DC side circuit breaker of the PV panel. 3) Turn off the DC switch of the inverter.
8. Don't insert or remove AC and DC terminals when the inverter is in normal operation.
9. The DC input voltage of the inverter must not exceed the maximum value of the model.



OPERATION INTERFACE

Interface View



Front panel display

Status Indicator

There are four LED status indicator lights in the front panel of the inverter.

INDICATOR	STATUS	EXPLANATION
<div><div></div>DC</div>	on	Inverter detects DC input
	off	Low DC input voltage
<div><div></div>AC</div>	on	Grid Connected
	off	Grid Unavailable
<div><div></div>NORMAL</div>	on	Under normal operating
	off	Stop operating
<div><div></div>ALARM</div>	on	Detected faults or report faults
	off	Under normal operating

Front panel display

## Buttons

There are four keys in the front panel of the Inverter (from left to right) : Esc, Up, Down and Enter keys. The keypad is used for:

- Scrolling through the displayed options (the Up and Down keys) ;
- Access to modify the adjustable settings (the Esc and Enter keys) .



## LCD Display

The two-line Liquid Crystal Display (LCD) is located on the front panel of the Inverter, which shows the following information:

- Inverter operation status and data;
- Service messages for operator;
- Alarm messages and fault indications.

## PRODUCT INSTALLATION


---

### Select installation location

To select a location for the inverter, the following criteria should be considered:

#### **WARNING: Risk of fire**

- Do not install the inverter in areas containing highly flammable materials or gases.
- Do not install the inverter in potentially explosive atmospheres.
- Do not install in small closed spaces where air can not circulate freely. To avoid overheating, always make sure the flow of air around the inverter is not blocked.
- Exposure to direct sunlight will increase the operational temperature of the inverter and may cause output power limiting. It is recommended that inverter installed to avoid direct sunlight or raining.
- To avoid overheating ambient air temperature must be considered when choosing the inverter installation location. It is recommended that using a sun shade minimizing direct sunlight when the ambient air temperature around the unit exceeds 104°F/40 °C .








Recommended installation place

- Install on a wall or strong structure capable of bearing the weight.
- Install vertically with a maximum incline of +15°. If the mounted inverter is tilted to an angle greater than the maximum noted, heat dissipation can be inhibited, and may result in less than expected output power.
- If install more than one inverter, must leave at least 500 mm gap between each inverter. And two adjacent inverters are also separated by at least 500 mm. And must install the inverter at the place where children cannot touch.
- Consider whether the installation environment is helpful to see the inverter LCD display and indicator status clearly.
- Must offer a ventilate environment if inverter installed in the airtight house




### Safety Hint

Do not place or store any items next to the inverter.



Installation Angle




Installation Angle

## Installations Tools


Installation tools can refer to the following recommended ones. Also, use other auxiliary tools on site.

### Tool specification




## Inverter Installation

The inverter is designed according to the wall mounted type installation, please use the wall mounted (the brick wall of the expansion bolt) when installing.




Procedure shows below:

1. Locate on the appropriate wall according to the bolt position on the mounting bracket, then mark the hole. On the brick wall, the installation must be suitable for the expansion bolt installation.



Inverter hanging plate installation

2. Ensure that the position of the installation holes on the wall is in accordance with the mounting plate, and the mounting rack is vertically placed.
3. Hang the inverter to the top of the mounting rack and then use the M4 screw in the accessory to lock inverter heat sink to the hanging plate, to ensure that the inverter will not move.



Inverter installation

## ELECTRICAL CONNECTION

### PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- 1) Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2) Open circuit Voltage (Voc) of PV modules should be higher than min. start voltage.
- 3) The PV modules used to connected to this inverter shall be Class A rating certified according to IEC 61730.

INVERTER MODEL	LT-40K F1	LT-45K F1	LT-50K F1
PV Input Voltage	600 V (250 V~1100 V)		
PV Array MPPT Voltage Range	200 V~1000 V		
No. of MPP Trackers	3		4
No. of Strings per MPP Tracker	3+3+3		3+3+3+3

### DC input terminal connection

1. Switch the Grid Supply Main Switch (AC) OFF.
2. Switch the DC Isolator OFF.
3. Assemble PV input connector to the inverter.



#### WARNING

When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.




#### SAFETY HINT

Before connection, please make sure the polarity of the output voltage of PV array matches the "DC+" and "DC-" symbols.




#### WARNING

Before connecting inverter, please make sure the PV array open circuit voltage is within the 1100V of the inverter.



DC+ male connector



DC- female connector

**SAFETY HINT**


Please use approved DC cable for PV system.

CABLE TYPE	CROSS SECTION ( mm <sup>2</sup> )	
	RANGE	RECOMMENDED VALUE
Industry generic PV cable (model: PV1-F)	2.5-4.0 (12~10AWG)	2.5 (12AWG)

**DC Cable Specifications**

The steps to assemble the DC connectors are listed as follows:

a) Strip off the DC wire about 7mm, disassemble the connector cap nut.



Disassemble the connector cap nut


b) Crimping metal terminals with crimping pliers as shown in picture below.



Crimp the contact pin to the wire


c) Insert the contact pin to the top part of the connector and screw up the cap nut to the top part of the connector.





connector with cap nut screwed on

d) Finally insert the DC connector into the positive and negative input of the inverter.



DC input connection



#### **WARNING**

Sunlight shines on the panel will generate voltage, high voltage in series may cause danger to life. Therefore, before connecting the DC input line, the solar panel needs to be blocked by the opaque material and the DC switch should be 'OFF', otherwise, the high voltage of the inverter may lead to lifethreatening conditions.



#### **WARNING**

Please use its own DC power connector from the inverter accessories. Do not interconnect the connectors of different manufacturers. Max. DC input current should be 20A. if exceeds, it may damage the inverter and it is not covered by LEDVANCE warranty.

#### **AC input terminal connection**


Do not close the DC switch after the DC terminal is connected. Connect the AC terminal to the AC side of the inverter, the AC side is equipped with Three phase AC terminals that can be conveniently connected. Flexible cords are recommended for easy installation.

**WARNING**

Prohibit using a single circuit breaker for multiple inverters, prohibit the connection of load between inverter circuit breakers.

MODEL	CABLE CSA	CABLE OUTER DIA	AWG	BREAKER	RECOMMEND COPPER CABLE ( mm <sup>2</sup> )	MAX CABLE LENGTH
LT-40/45K F1	16 mm <sup>2</sup>	25-40 mm	4	80 A/ 400 V	16 mm <sup>2</sup>	Outside cable (3L+N+PE) 20 m
LT-50K F1	25 mm <sup>2</sup>	25-40 mm	2	90 A/ 400 V	25 mm <sup>2</sup>	

Cable information



AC input connection

**WARNING**


Be sure that AC power source is disconnected before attempting to wire it to the unit.

1. Before making Grid port connection, be sure to turn off AC baeaker or disconnector first.
2. Remove insulation sleeve 10mm length, unscrew the bolts, insert the wires according to polarities indicated on the terminal block and tighten the terminal screws. Make sure the connection is complete.
3. Then, insert AC output wires according to polarities indicated on the terminal block and tighten terminal. Be sure to connect corresponding N/L1/L2/L3 and PE wires to related terminals as well.
4. Make sure the wires are securely connected.

### The connection of the ground line

Good grounding is good for resisting surge voltage shock and improving EMI performance. Therefore, before connecting AC, DC and communication cables, you need to ground the cable firstly.

For a single system, just ground the PE cable. For multiple machine systems, all PE cables of the inverter need to be connected to the same grounding copper platoon to ensure the equipotential connection. The installation of the shell ground wire is shown as picture below. The external protective earthing conductor is made of the same metal as the phase conductor.



The installation of the shell ground wire

MODEL	WIRE SIZE	CABLE ( mm <sup>2</sup> )	RECOMMEND COPPER CABLE ( mm <sup>2</sup> )	TORQUE VALUE (MAX)
LT-40/45/50K F1	4 AWG	16 mm <sup>2</sup>	16 mm <sup>2</sup>	12.4 Nm

**WARNING**

Inverter has built-in leakage current detection circuit, The type A RCD can be connected to the inverter for protection according to the local laws and regulations.

If an external leakage current protection device is connected, its operating current must be equal to 10mA/ KVA or higher, otherwise inverter may not work properly.

**Max. over current protection device**


In order to protect the inverter AC connection, it is recommended to install a circuit breaker to prevent overcurrent.

INVERTER	RATED OUTPUT VOLTAGE (V)	RATED OUTPUT CURRENT (A)	CURRENT FOR PROTECTION DEVICE (A)
LT-40K F1	220/230	60.6/58 A	80
LT-45K F1	220/230	68.2/65.2 A	80
LT-50K F1	220/230	75.8/72.5 A	90

Recommended current protector specifications

**Inverter monitoring connection**


Inverter has the function of wireless remote monitoring. The inverter with Wi-Fi function is equipped with Wi-Fi Plug to connect the inverter and network. Wi-Fi Plug's operation, installation, Internet access, APP downloading and other processes are detailed in the instructions.



Internet monitoring solution

## Installation of datalogger

When installing the Wi-Fi stick, tear off the sealing strip on the inverter. Insert the datalogger into the interface and fix it with a screw. The configuration of the datalogger needs to be performed after various electrical connections have been completed and the inverter DC power on. When the inverter is on the DC power, it is determined whether the datalogger is normally electrified (The LED light shines out of the shell)



Internet monitoring solution

## Configuration of datalogger

For the configuration of datalogger, please refer to illustrations of the datalogger.

## STARTUP AND SHUTDOWN

---

Before starting the inverter, make sure that the inverter can meet the following conditions, otherwise it may result in fire or damage to the inverter. In this case, we do not undertake any responsibility. At the same time, to optimize the system configuration, it is recommended that the two inputs be connected to the same number of photovoltaic modules.

- a) The maximum open circuit voltage of each set of photovoltaic modules shall not exceed 1100Vdc under any conditions.
- b) Each input of the inverter better use the same type of photovoltaic module in series.
- c) Total output power of PV shall not exceed the maximum input power of inverter, each photovoltaic modules shall not exceed the rated power of each channel.

### Start up the inverter

When starting up the three phase string inverter, should follow steps below :

- 1. Starting switch on the AC breaker.
- 2. Turn on the DC switch of the photovoltaic module, and if the panel provides sufficient starting voltage and power, the inverter will start.
- 3. The inverter will first check the internal parameters and the grid parameters, while the liquid crystal will show that the inverter is self-checking.
- 4. If the parameter is within acceptable range, the inverter will generate energy. NORMAL indicator light is on.

### Inverter Shutdown

Must follow below steps while shutting down the inverter:

- 1. Switch off the AC breaker.
- 2. Wait for 30 seconds, turn off the DC switch (if any) , or simply disconnect the DC input connector. The inverter will close the LCD and all LED within two minutes.

## ZERO-EXPORT FUNCTION VIA ENERGY METER

---


When you are reading this, we believe that you have completed the connection according to the requirements of chapter 5, if you have been running your inverter at this time, and you want to use the zero-export function, please turn off AC and DC switch of the inverter, and wait for 5 minutes until the inverter completely discharged.

For system wiring diagram, the red line refers to L line (L1, L2, L3) , the black line refers to the neutral line (N) . Connecting energy meter RS485 cable to inverter's RS485 port. It's recommended to install an AC switch between the inverter and the utility grid, the specs of the AC switch are determined by the power of load.


If there is no integrated DC switch inside the inverter you purchased, we commend you to connect the DC switch. The voltage and current of the switch depend on the PV array you access.



Eastron SDM630-Modbus V2



Eastron meter



Connection diagram of Eastron meter




### WARNING

In final installation, breaker certified according to IEC 60947-1 and IEC 60947-2 shall be installed with the equipment.









Eastron SDM630MCT

Eastron meter




Connection diagram of Eastron meter



Eastron SDM630MCT

Eastron meter



Connection diagram of Eastron meter

## Multiple strings and parallel connection meters

This application is that when the string inverters work in parallel, there is only one power grid and one load, and only one meter can be connected to prevent reverse current, so only this many-to-one anti-reverse current connection can be connected.

If there's several inverters in a plant, also it can use 1pcs meter to realize zero export function. For example,if there's 3pcs inverter in the system with 1pcs meter.We need to setup 1pcs inverter as the master and others setup as slaves. And, all of them need to connect to the meter via RS485. Below is the system diagram and configuration of the system.

Meter	OFF <<	Exp_Mode	AUG <<
Limiter	OFF	CT_Ratio	0
MFR	ACREL	Shunt	OFF
FeedIn	0.0KW <<	ShuntQTY	1 <<
Generator	ON	G_MFR	CHNT
G_CT	1 <<	G_Pout	0% <<
G_Cap	0.0KW		
Back<<			

Meter function


NAME	DESCRIPTION	RANGE
Exp_Mode	AVG: Average power of three phase is zero exported. MIN: Phase with minimum load power is zero exported, while the other two phase may be in purchase mode.	AVG/MIN
CT_Ratio	CT ratio of power grid side meter when extern CT is applied.	1-1000
MFR	Manufacturer of the grid side meter. Modbus Address of it should be set as 01.	EASTRON
Feedin	Percentage of the Feed in power exported to the grid.	0-110 %
Shunt	Parallel mode. Set one inverter as Master, others are Slave. ONLY need to set the master, Slave will follow the settings in the master.	OFF/Master / Slave
ShuntQTY	Number of inverters in parallel	1-16
Generator	DGside meter function Enable/Disable	ON/OFF
G.CT	CT ratio of power DGside meter when extern CT is applied.	1-1000
G.MFR	Manufacturer of the DG side meter. Modbus Address of it should be set as 02.	EASTRON
G.Cap	Capacity of the DG.	1-999 kW

**Note:**


Select Meter option in Run Param and long press ENTER button to enter this Meter Setting page.




Eastron SDM630-Modbus V2



Eastron meter




Eastron Connection diagram (The pass-through table)



Eastron SDM630-Modbus V2

Eastron meter




Eastron Connection diagram (The pass-through table)






Eastron SDM630MCT



Eastron meter




Connection diagram (Three-phase electricity )






Eastron SDM630MCT



Eastron meter




Connection diagram (Three-phase electricity )

## Use of zero-export function

When the connection is completed, the following steps should be referred to use this function:

1. Turn on the AC switch.
2. Turn on the DC switch, waiting for the inverter's LCD is turned on.
3. Press Enter button on the LCD panel in the main interface into the menu options, select [parameter setting] to enter setup submenu, and then select [running parameters] as shown in picture 7.34, at this time please input the default password 1234 through pressing the button [up down, enter], enter the operation parameter setting interface, shown as picture below.



Parameter setting



Meter switch

4. Operate the button [up down], move setting cursor to energy meter and press the button [enter]. At this time you can turn on or turn off the energy meter by choosing [up down] button, please press [enter] button to confirm when setting done.
5. Move the cursor to [OK], press [enter] to save the settings and exit the running parameters page, otherwise the settings are invalid.
6. If set up successfully, you can return to the menu interface, and display the LCD to [home page] by press the [up down] button. If it displays [meter power XXW], the zero-export function setting is completed.



Zero-export function via energy meter turn on

7. Meter power XXW shows positive means grid is supplying the load, and no power fed into grid. if meter power shows negative, it means PV energy is being sold to grid or energy meter wiring connction has problem.
8. After properly connection is done, wait for inverter starting. If the power of the PV array meets the current power consumption, the inverter will keep a certain output to counteract the power of the grid without backflow .

### Notes while using zero export function

For your safety and the operation of limiter function of the inverter, we put forward the following suggestions and precautions:



#### **SAFETY HINT**

Under zero export mode we strongly recommend that the two PV arrays are formed by the same number of PV panels of the same size, which will make the inverter more responsive to limit the power.





#### **SAFETY HINT**

While the utility power is negative and inverter has no output power, that means the orientation of the current sensor is wrong, please turn off the inverter and change orientation of the current sensor.


# GENERAL OPERATION

During normal operation, the LCD shows the current status of the inverter, including the current power, total generation, a bar chart of power operation and inverter ID,etc. Press the Up key and the Down key to see the current DC voltage, DC current, AC voltage, AC current,inverter radiator temperature,software version number and Wi-Fi connection state of the inverter.





**\*Note:** These parameters will be available after the meter is connected successfully. Otherwise, it won't show.  
**Attention:** For running param detail on the LCD display, please refer to the official LEDVANCE website <https://www.LEDVANCEinverter.com>.




## The initial interface

From the initial interface, you can check PV power, PV voltage, grid voltage, inverter ID, model and other information.



The initial interface


Press UP or Down, you can check inverter DC voltage, DC current, AC voltage, AC current and inverter temperature.




PV input voltage and current




Load power



Grid voltage and current information




Grid voltage and frequency



PV generation

E-Day: Daily generation;  
E-Total: Total generation.



Time



Meter power

**LoadEp: 0.00KWh**

**Total : 0.00KWh**

Load consumption

LoadEp: Daily consumption;  
Total: Total energy consumption.

**ImpEp: 0.00KWh**

**Total : 0.00KWh**

Electrical energy

ImpEp: Daily energy purchased from grid;  
Total: Total energy purchased from grid.

**ExpEp: 0.00KWh**

**Total : 0.00KWh**

Electrical energy

ExpEp: Daily energy sold to grid;  
Total: Total energy sold to grid.

### Submenus in the Main Menu

There are five submenus in the Main Menu.

### Device information

You can see the LCD software VerA238 and control board software Ver1400. In this interface, there are parameters such as rated power communication addresses.

**Device Info. <<**

**Fault Record**

**GL3000 SN-01**

**PF: 0.000**

**ID:2104149060**

**Inv1400**

**Inv1400**


**LcdA244**

Device information

### Fault Record


It can keep Eight fault records in the menu including time, customer can deal with it depends on the error code.





Fault Record

### ON/OFF setting



ON/OFF setting

When the inverter is turned off, it stops working immediately, and go to standby mode and then will go to self-test program again. If it passed the self-test, it will start to work again.

### Parameter setting


There are five submenus in the setup. Setting includes system param, run param, protect param, comm: param. All of these information for maintenance reference.



Submenus of the parameter setup

## System param setting

System Param includes time set, language set, display set and factory reset.



System Param



Time



Language



LCD Screen settings



Delay time set



Reset to factory setting



Set Restore

## Protect Param setting



### WARNING

Engineer Only.

We will set the param depends on the safety requirements, so customers don't need to reset it. The password is same as 8.4 Running param

<b>Password</b> * * * *	<b>GridStanderd &lt;&lt;</b> <b>Advanced</b>
<b>Back &lt;&lt;</b>	

Password

<b>Braszil</b> <b>EN50549-1-PL &lt;&lt;</b>	<b>EN50549-1</b> <b>IEC61727 &lt;&lt;</b>
<b>CUSTOM</b> <b>VDE4105 &lt;&lt;</b>	<b>VDE0126</b> <b>Spain &lt;&lt;</b>
<b>CEI_0-21</b> <b>G98 &lt;&lt;</b>	<b>G99</b> <b>NBT32004-B &lt;&lt;</b>
<b>Australia-A</b> <b>Australia-B &lt;&lt;</b>	<b>Australia-C</b> <b>New Zealand &lt;&lt;</b>
<b>MEA</b> <b>PEA &lt;&lt;</b>	<b>Norway</b> <b>Switzerland &lt;&lt;</b>
<b>R25</b> <b>OK Cancel &lt;&lt;</b>	

OverVolt	Lv3	Point	240,0V <<
OverVolt	Lv3	Delay	1000ms <<
OverVolt	Lv2	Point	240,0V <<
OverVolt	Lv2	Delay	1000ms <<
OverVolt	Lv1	Point	240,0V <<
OverVolt	Lv1	Delay	1000ms <<
UnderVolt	Lv1	Point	235,0V <<
UnderVolt	Lv1	Delay	1000ms <<
UnderVolt	Lv2	Point	235,0V <<
UnderVolt	Lv2	Delay	1000ms <<
UnderVolt	Lv3	Point	235,0V <<
UnderVolt	Lv3	Delay	1000ms <<
OverFreq	Lv3	Point	52,00Hz <<
OverFreq	Lv3	Delay	1000ms <<
OverFreq	Lv2	Point	52,00Hz <<
OverFreq	Lv2	Delay	1000ms <<
OverFreq	Lv1	Point	52,00Hz <<
OverFreq	Lv1	Delay	1000ms <<
UnderFreq	Lv1	Point	48,00Hz <<
UnderFreq	Lv1	Delay	1000ms <<



UnderFreq Lv2 Point 48,00Hz <<	UnderFreq Lv2 Delay 1000ms <<
UnderFreq Lv3 Point 48,00Hz <<	UnderFreq Lv3 Delay 1000ms <<
Reconnection Vup 0,0V <<	Reconnection Vdown 0,0V <<
Reconnection Fup 0,00Hz <<	Reconnection Fdown 0,00Hz <<
OV 10 Minutes Enable OFF <<	OV 10 Minutes Point 0,0% <<
Point 0,0% Grid --- <<	OK Cancel <<

"CUSTOMIZED"

Please set the proper grid parameters according to the requirements of your current country's grid regulations.If you are not clear about it, please consult your installer.

#### Comm. param setting

Address: 01 << BaudRate: 9600	Func: Meter Address1: 01 <<
----------------------------------	--------------------------------

Comm. Param

## REPAIR AND MAINTENANCE

---

String type inverter doesn't need regular maintenance. However, debris or dust will affect heat sink's thermal performance. It is better to clean it with a soft brush. If the surface is too dirty and affect the reading of LCD and LED lamp, you can use wet cloth to clean it up.



### **High Temperature Hazard**

When the device is running, the local temperature is too high and the touch can cause burns. Turn off the inverter and wait for it cooling, then you can clean and maintain.



### **Safety Hint**

No solvent, abrasive materials or corrosive materials can be used for cleaning any parts of the inverter.

## ERROR INFORMATION AND PROCESSING

Inverter has been designed in accordance with international grid tied standards for safety, and electromagnetic compatibility requirements. Before delivering to the customer the inverter has been subjected to several tests to ensure its optimal operation and reliability

### Error code

If there is any failure, the LCD screen will display an alarm message. In this case, the inverter may stop feeding energy into the grid. The alarm description and their corresponding alarm messages are listed below.

ERROR CODE	DESCRIPTION	ONGRID - THREE PHASE
F01	DC input polarity reverse fault	Check the PV input polarity.
F02	DC insulation impedance permanent fault	Check the grounding cable of inverter.
F03	DC leakage current fault	Hardly appear the code. Never ever happened so far.
F04	Ground fault GFDI	Check the solar panel output connection.
F05	Read the memory error	Failure in reading memory (EEPROM) . Restart the inverter if the fault still exists, contact your installer or LEDVANCE service.
F06	Write the memory error	Failure in writing memory (EEPROM) . Restart the inverter if the fault still exists, contact your installer or LEDVANCE service.
F07	GFDI blown fuse	Hardly appear the code. Never ever happened so far.
F08	GFDI grounding touch failure	Hardly appear the code. Never ever happened so far.
F09	IGBT damaged by excessive drop voltage	Hardly appear the code. Never ever happened so far.
F10	Auxiliary switch power supply failure	1. It tells the DC12V is not existed. 2. Restart the inverter, if the fault still exists, please contact your installer or LEDVANCE service.
F11	AC main contactor errors	Hardly appear the code. Never ever happened so far.
F12	AC auxiliary contactor errors	Hardly appear the code. Never ever happened so far.
F13	reserved	1. Loss of one phase or AC voltage detection part failure or relays not closed. 2. Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.
F14	DC firmware over current	Hardly appear the code. Never ever happened so far.
F15	AC firmware over current	1. The internal AC sensor or detection circuit on control board or connection wire may loose. 2. Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.

ERROR CODE	DESCRIPTION	ONGRID - THREE PHASE
F16	GFCI (RCD) Ac leakage current fault	<p>1. This fault means the average leakage current is over 300mA. Check whether DC power supply or solar panels is ok, then check 'Test data' -&gt; 'diL' value is about 40; Then check the leakage current sensor or circuit (the following picture) . Checking test data needs using big LCD.</p> <p>2. Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.</p>
F17	Three phase current, over-current fault	Hardly appear the code. Never ever happened so far.
F18	AC over current fault of hardware	<p>1. Check AC sensor or detection circuit on control board or connection wire.</p> <p>2. Restart the inverter or factory reset, if the error still exists, please contact your installer or LEDVANCE service.</p>
F19	All hardware failure synthesis	Hardly appear the code. Never ever happened so far.
F20	DC over current fault of the hardware	<p>1. Check whether solar panel output current is within the allowed range.</p> <p>2. Check DC current sensor and its detection circuit.</p> <p>3. Check if the inverter FW version is suitable for the hardware.</p> <p>4. Restart the inverter, if the error still exists, please contact your installer or LEDVANCE service.</p>
F21	DC leakage flow fault	Hardly appear the code. Never ever happened so far.
F22	Crash stop (if there is a stop button)	Contact your installer for help.
F23	AC leakage current is transient over current	<p>1. This fault means the leakage current is above 30mA suddenly. Check whether DC power supply or solar panels is ok, then check 'Test data' -&gt; 'diL' value is about 40; Then check the leakage current sensor or circuit. Check test data needs using big LCD.</p> <p>2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.</p>
F24	DC insulation impedance failure	<p>1. Check Vpe resistance on main board or detection on control board. Check PV panels is OK. Many times this issue is the PV problem.</p> <p>2. Check whether the PV panel (aluminum frame) is grounded well and inverter is grounded well. Open the cover of inverter and then check the inside ground cable is fixed well on the shell.</p> <p>3. Check if the AC/DC cable, terminal block are shorted to ground or the insulation is damaged.</p> <p>4. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.</p>
F25	DC feedback fault	Hardly appear the code. Never ever happened so far.
F26	The DC busbar is unbalanced	<p>1. Check whether the 'BUSN' cable or driver board power supply cable is loose.</p> <p>2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.</p>



ERROR CODE	DESCRIPTION	ONGRID - THREE PHASE
F27	DC end insulation error	Hardly appear the code. Never ever happened so far.
F28	Inverter 1 DC high fault	Hardly appear the code. Never ever happened so far.
F29	AC load switch failure	Hardly appear the code. Never ever happened so far.
F30	AC main contactor failure	1. Check relays and AC voltage of relays. 2. Check relays driver circuit. Check if the software is not suitable for this inverter. (Old inverter not have relays detection function) 3. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F31	Relay open circuit fault	1. At least one Relay can't be closed. Check relays and its driver signal. (Old inverter not have relays detection function) 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F32	Inverter 2 dc high fault	Hardly appear the code. Never ever happened so far.
F33	AC over current	Hardly appear the code. Never ever happened so far.
F34	AC current over load	Hardly appear the code. Never ever happened so far.
F35	No AC grid	1. Check AC grid voltage. Check AC voltage detection circuit. Check if the AC connector in good condition. Check whether the AC grid is normal in voltage. 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F36	AC grid phase error	Hardly appear the code. Never ever happened so far.
F37	AC three-phase voltage unbalance failure	Hardly appear the code. Never ever happened so far.
F38	AC three-phase current unbalance failure	Hardly appear the code. Never ever happened so far.
F39	AC over current (one cycle)	1. Check AC current sensor and its circuit. 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F40	DC over current	Hardly appear the code. Never ever happened so far.
F41	AC LineW,U over voltage	Check the AC voltage protection setting. And Check if the AC cable is too thin. Check the voltage difference between LCD and meter.
F42	AC LineW,U low voltage	Check the AC voltage protection setting. Check the voltage difference between LCD and meter. Also need to check whether AC cables are all firmly and correctly connected.
F43	AC Line V,W over voltage	Check the AC voltage protection setting. And Check if the AC cable is too thin. Check the voltage difference between LCD and meter.
F44	AC Line V,W low voltage	Check the AC voltage protection setting. Check the voltage difference between LCD and meter. Also need to check whether AC cables are all firmly and correctly connected.

ERROR CODE	DESCRIPTION	ONGRID - THREE PHASE
F45	AC Line U,V over voltage	Check the AC voltage protection setting.And Check if the AC
F46	AC Line U,V low voltage	Check the AC voltage protection setting.
F47	AC Over frequency	Check the frequency protection setting.
F48	AC lower frequency	Check the frequency protection setting.
F49	U phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F50	V phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F51	W phase grid current DC component over current	Hardly appear the code. Never ever happened so far.
F52	AC inductor A, phase current DC current high	Hardly appear the code. Never ever happened so far.
F53	AC inductor B, phase current DC current high	Hardly appear the code. Never ever happened so far.
F54	AC inductor C, phase current DC current high	Hardly appear the code. Never ever happened so far.
F55	DC busbar voltage is too high	1. Check PV voltage and Ubus voltage and its detection circuit. If the PV input voltage exceeds the limit, please reduce the number of solar panels in series. 2. For Ubus voltage, please check the LCD display
F56	DC busbar voltage is too low	1. It tells the PV input voltage is low and it always happens in the early morning. 2. Check PV voltage and Ubus voltage. When inverter is running, then showing F56, maybe Loss of driver or need update firmware. 3. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.
F57	AC reverse irrigation	AC reverse irrigation.
F58	AC grid U over current	Hardly appear the code. Never ever happened so far.
F59	AC grid V over current	Hardly appear the code. Never ever happened so far.
F60	AC grid W over current	Hardly appear the code. Never ever happened so far.
F61	Reactor A phase over current	Hardly appear the code. Never ever happened so far.
F62	Reactor B phase over current	Hardly appear the code. Never ever happened so far.
F63	ARC fault	1. Check PV module cable connection and clear the fault; 2. Seek help from us, if can not go back to normal state.
F64	IGBT heat sink high temperature	1. Check temperature sensor. Check if firmware is suitable for the hardware. Check if the inverter is its right model. 2. Restart the inverter, if the fault still exists, contact your installer or LEDVANCE service.

Error codes and their solutions

**Safety Hint**

If your string inverter has any of the fault information shown in Table 10-1, and when you reset the machine and still don't solve the problem, please contact our distributor and provide the below details:

1. Serial number of the inverter;
2. The distributor/dealer of the inverter (if available) ;
3. Installation date;
4. The discription of problem (include LCD'error code and LED starus indicator lights) ;
5. Your contact details.

## SPECIFICATION

MODEL	LT-40K F1	LT-45K F1	LT-50K F1
<b>PV String Input Data</b>			
Max. PV Input Power (kW)	52	58.5	65
Max. PV Input Voltage (V)	1100		
Start-up Voltage (V)	250		
PV Input Voltage Range (V)	250-1100		
MPPT Voltage Range (V)	200-1000		
Rated PV Input Voltage (V)	600 V		
Full Load MPPT Voltage Range (V)	450-850		
Max. Input Short Circuit Current (A)	60+60+60	60+60+60	60+60+60+60
Max. Operating PV Input Current (A)	40+40+40	40+40+40	40+40+40+40
No. of MPP Trackers/No. of Strings per MPP Tracker	3/3+3+3	3/3+3+3	4/3+3+3+3
Max. Inverter Backfeed Current To the Array	0		
<b>AC Output Data</b>			
Rated AC Output Active Power (kW)	40	45	50
Max.AC Output Apparent Power (kVA)	44	49.5	55
Rated AC Output current (A)	60.6/58	68.2/65.2	75.8/72.5
Max.AC Output Current (A)	66.7/63.8	75/71.7	83.3/79.7
Max. Output Fault Current (A)	116	130.4	145
Max. Output Overcurrent Protection (A)	132.5	132.5	157.9
Rated Output voltage/range (V)	220/380 V 230/400 V 0.85 Un-1.1 Un		
Grid Connection Form	3L+N+PE		
Rated Output Grid Frequency/range (Hz)	50 Hz/45 Hz-55 Hz, 60 Hz/55 Hz-65 Hz		
Power Factor Adjustment Range	0.8 leading-0.8lagging		
Total Current Harmonic Distortion THDi	< 3%		
DC Injection Current	<0.5 % In		

MODEL	LT-40K F1	LT-45K F1	LT-50K F1
Efficiency			
Max.Efficiency	98.7 %		
Euro Efficiency	98.1%		
MPPT Efficiency	> 99 %		
Equipment Protection			
DC Polarity Reverse Connection Protection	yes		
AC Output Overcurrent Protection	yes		
AC Output Overvoltage Protection	yes		
AC Output Short Circuit Protection	yes		
Thermal Protection	yes		
DC Terminal Insulation Impedance Monitoring	yes		
DC component monitoring	yes		
Ground fault current monitoring	yes		
Power Network Monitoring	yes		
Island protection monitoring	yes		
Earth Fault Detection	yes		
DC Input Switch	yes		
Overvoltage Load Drop Protection	yes		
Residual Current (RCD) Detection	yes		
Surge Protection Level	TYPE II (DC) ,TYPE II (AC)		
Interface			
Communication Interface	RS485/RS232		
Monitor Mode	GPRS/Wi-Fi/Bluetooth/4G/LAN (optional)		
Display	LCD+LED		
General Data			
Operating Temperature Range (°C)	-25 to +60 °C ,> 45 °C derating		
Permissible Ambient Humidity	0-100%		
Permissible Altitude (m)	4000m		

MODEL	LT-40K F1	LT-45K F1	LT-50K F1
Noise (dB)	< 65 dB		
Ingress Protection (IP) Rating	IP 65		
Inverter Topology	Non-Isolated		
Over Voltage Category	OVC II (DC) ,OVC III (AC)		
Cabinet Size (W*H*D) [mm]	434×570×243 (Excluding connectors and brackets)		
Weight [kg]	39		
Warranty [year]	Standard 5 years, extended warranty		
Type Of Cooling	Intelligent air cooling		
Grid Regulation	IEC 61727, IEC 62116, CEI 0-21, EN 50549, NRS 097, RD 140, UNE 217002, OVE-Richtlinie R25, G99,VDE-AR-N 4105		
Safety EMC/Standard	IEC/EN 61000-6-1/2/3/4, IEC/EN 62109-1, IEC/EN 62109-2		

## EU DECLARATION OF CONFORMITY

---

within the scope of the EU directives

- Electromagnetic compatibility 2014/30/EU (EMC)
- Low Voltage Directive 2014/35/EU (LVD)
- Restriction of the use of certain hazardous substances 2011/65/EU (RoHS)

